

TO CLIMB SAFELY USING THE SELF-BELAY-DEVICE

1. Children must be constantly supervised.



2. The climbing harness is positioned above the hip bone and all three safety buckles are fastened.



3. The carabiner is closed correctly and tied to the tie-in point (always checked by the supervising person).



4. Climbing with the self-belay-device is only permitted within the area marked by the red tarpaulin.

